## **Safety**

- 1. When pulverizer is in operation, do not go near the spinning shaft and tines.
- 2. Be very aware of where others are when operating the pulverizer.
- 3. Debris can and will be ejected to the sides of the pulverizer bucket. Keep bystanders well away and ensure everyone is wearing safety glasses to prevent eye injury.

## **Troubleshooting**

See: Hydraulics System Troubleshooting

## **User Responsibilities**

The User takes on the full responsibility of using the plans to build a CEB machine, by ensuring that the User follows all CEB build, safety, maintenance, and operation procedures. It is the duty of the User to accept that accidents and unforeseen circumstances may occur by using, and that such happenings may place the User in danger of injury or even death. The User agrees to not hold OSE liable for any accidents or deaths, and the User agrees to not pursue any legal action against OSE and his or her agents and collaborators in the case of harm, injury, or death resulting from use of the Machine, regardless of the cause or reason for the accident. It is the duty of the User and his/her collaborators or work crew to read and understand the Assembly, Setup and Testing Procedure, Machine Adjustment, Troubleshooting, and all of the above safety, maintenance, and operation procedures. Furthermore, the User agrees to not solicit the services of any agents, assigns, or other third parties to pursue legal action against the Producer in the case of accidents or death related to use of the Machine. If the User allows any other person or group to use the machine or participate in brick production, the User likewise agrees to take on the full responsibility and liability associated with any harm or injury that may happen to anyone involved in using the Machine, and shall hold the Producer in indemnity.

Therefore, the User hereby agrees to release and forever discharge OSE from any and all liability, claims, and demands of whatever kind either in law or in equity, which arise or may hereafter arise from the building or use of the Machine by: (1), the User, (2), others involved with the User in the build or use of the Machine, and (3), others to whom the User grants use of the Machine. The User furthermore agrees and understands that this contract discharges OSE from any liability or claim that the User may have against OSE with respect to bodily injury, personal injury, or property damages that may result from the User's and Beneficiary's production or use of the machine, wherever the Machine may be used. The User also understands that the Producer does not assume any responsibility for or obligations to provide financial or other assistance, including but not limited to medical, health, or disability insurance in the event of injury or loss – unless OSE agrees to help the User or Beneficiary out of voluntary, good faith and honor.